

*Q: TimeFactor/ModFactor alters my tone, adding brightness to the signal. Why?*

A: When used with some low impedance tube amps it may sound like TimeFactor/ModFactor is adding brightness when Active because it is acting as a buffer. This is really letting you hear the highs that were lost from your signal without a buffer. Many amps have buffered effects loops to address this issue. In this case we recommend that you connect our Stompboxes through the effects loop of these amps. If your amp does not have an effects loop, or if you prefer to run our Stompboxes in front of the amp (after the guitar before the amp's input,) a solution would be to always have a buffer pedal in the signal chain before TimeFactor/ModFactor (if using relay Bypass) or simply always use DSP Bypass mode.